

LIMITED PRODUCT WARRANTY

Newline warrants its products to be free from defects in material and workmanship for a period of one year from the date of shipment. Any product found to be defective within this time period may be returned to Newline, freight prepaid by buyer, with prior return authorization for repair or replacement at no charge. Any damage on the products which resulted from mishandling, physical abuse, accident, unauthorized service or product abuse will have the warranty voided immediately.

Newline's liability under this warranty is limited to the repair or replacement of the defective product and in no event shall Newline be liable for consequential or indirect damages to equipment or personnel. Nor shall Newline be liable for damages to equipment or personal injury caused by misuse, overload, accidental damage, alteration, improper installation or unauthorized opening of the equipment. Under no circumstances will Newline be responsible for any indirect or consequential damages due to errors in weighing or failure of a Newline product to perform properly.

To request warranty service, please email your claim with invoice # to our Service Department, service@newlinescale.com, to request a RMA#. You can also fill out the RMA form from our web site www.newlinescale.com

NEWLINE®

DIGITAL KITCHEN SCALE

INSTRUCTION

For the purpose of proper using & maintaining the scale, please read this instruction completely before operating.



EXCLUSIVE
SensorDisc
TECHNOLOGY

LONG LIFE
BATTERY

RoHS


Electronic Kitchen Scale

SPECIFICATIONS

- Equipped with high precision strain gauge sensor system
- Capacity: 2000g/1g 3000g/1g 5000g/1g 5000g/2g
- Over-load/Low power indicator
- Auto zero resetting/ power off
- Tare function
- Unit switch: g/oz

POWER SUPPLY

- Battery: 2XCR2016 1XCR2032 1X9V 2XCR2032
- When the LCD indicate "+-", open the battery door and replace the battery with a new one.
- Note: For lithium battery (Cr2032) powered scale, please pull the insulation tape out before first use.



OPERATION

- STEP1: Put the kitchen scale on a hard and flat surface;
STEP2: Press "ON/OFF" key, the scale will be zero in 3 seconds;
STEP3: Put the food into the container, the weight will be displayed.



TARE

(TO WEIGH DIFFERENT INGREDIENTS IN THE SAME CONTAINER)

Leave the first load of ingredient in the container, press "TARE" to reset the display to "0", add the next ingredient load to the container and the net weight will be displayed; and repeat for next ingredient load.



SWITCH OFF

- After finished weighing, press the "ON/OFF" key.
- The scale will automatically switch off after approximate one minute of idle time.

UNIT SWITCH

Press "UNIT" key to switch the unit to "g" or "oz"



OVER-LOAD INDICATOR

When the scale is overload 2000g 3000g 5000g
"EEEE" will appear on the screen



ADVICE FOR USE AND CARE

- Placing the scale on a hard flat surface will ensure reliable and accurate readings.
- Clean the scale with damp cloth, but do not allow water to enter the unit.
- Do not use chemical abrasive cleaners
- Do not allow the scale to become immersed in water or exposed under strong sunlight.
- Do not drop or subject the scale to shocks as this may damage the unit.
- Only store flat.
- Remove the battery if the scale is not to be used for a long period
- Do not use for legal trade.

