

Electronic Portable Kitchen Scale



INSTRUCTIONS

Electronic Protable Kitchen Scale










INSTRUCTIONS ITEM:SAK9161



For the purpose of proper using and maintaining the kitchen scale, please read this instruction completely before operating.

SPECIFICATION

- High precision strain gauge sensor system
- Over-load/ lower power indicator

Weight unit: g-oz


- Capacity:3000g×1g; Foldable scale body
 - Automatic zero resetting / auto power off
- With electronic clock and count down timer
 - Tare function
- Capacity: 3000g/105.8oz Min. effective: 20g/0.7oz; Division: 1g/0.1oz

POWER SUPPLY =

Battery:2x1.5V AAA battery(not included)


FOR FIRST USING

Turn around the scale, battery box is on the back of scale, open the battery box and insert the battery with correct



OPERATION


- STEP1. Slightly unfold the scale and put it on a hard flat surface.(Please make sure all 4 legs stand firm on the hard surface)
- STEP2. Put a glass plate or container $(\geq \Phi 150 \text{mm})$ on the scale and make sure it is hard and centered.(The glass platform is not included.)



STEP3. Press the key of "ON/TARE", the LCD will show zero after "HELO" appeared. Now it enters the weighing



STEP4. Put the food on the glass or container, LCD will show the food weight.



STEP6. Fold the scale after finished using.

NOTE: 1). Under the weight mode. If no operation on the scale for 60 seconds, The system will enter time mode automatically.


> 2). Place the goods at the middle of glass/container will ensure reliable and accurate readings 3). Do not put the food direct on the scale.





TARE(zero resetting)

Step 1 Under weight mode, put the container or glass on the scale, LCD will show the weight of container or glass.











Step 2 Press the key of "ON/TARE", after about 2 seconds the LCD will reset to zero(clear the weight of the container or glass plate), then put the food into container or glass plate, the LCD will show the food weight only. Repeat to press "ON/TARE" key for more different ingredients.











TIME SETTING

When the system is under time mode, hold "MODE" key for at least 3 seconds to enter the setting mode.



Press "UNIT" to set the 'hour'.



will twinkle on the LCD.

Press "MODE" again, the 'hour'



"MODE" key to repristinate.

Press "UNIT" to set the 'hour'.

When finish setting, press

S_____S

8:30

NOTE: If there is no operation for 20 seconds under time setting state, the system will enter time mode automatically

COUNTDOWN TIMER SETTING

Step 1 When the system is under time mode, press "MODE" key once to enter the timer setting.



Step 2 Hold the "MODE" key till the 'second' twinkle on the LCD.



Step 3 Press "UNIT" key to set the desired countdown second.



Step 4 Press "MODE", the 'minute' will twinkle on the LCD.



Step5 Press "UNIT" key to set the desired countdown minute.



Step6 After finished timer setting, press "MODE" to start counting down.



When counting down time is over, "00:00" will appear on the LCD, and the alarm will ring.Press "MODE" to stop alarm ring.



NOTE: If there is no operation for 20 seconds under time setting state, the system will enter time mode automatically

Under the weight mode, press "UNIT" key to chose the unit "g" or "oz" .





OVER-LOAD INDICATOR

When the scale is over loaded(3000g) The "Err" will appear on the display




LOW POWER INDICATOR


replace the battery with a new one -7/4


ACCESSORIES

■ The scale is packed with one of the below accessories, please handle it carefully when folding and putting the scale inside the sheath. Incorrect or mishandling may scratch the appearance of the scale.









2000

ADVICE FOR USE AND CARE

- 1.Do not drop or subject the scales to shocks as this may damage the unit.
- 2.Do not use abrasive chemical cleaners
- 3.Clean the scales with a damp cloth, but do not allow water to enter the unit.
- 4. To ensure the life of the scale, please do not put it in the wet and hot environment.
- 5.Please remove the battery from the scales if it has not been used for a long period.
- 6.This scale is for family use only and should not be used commercially for any reason at all.









