

LIMITED PRODUCT WARRANTY

Newline warrants its products to be free from defects in material and workmanship for a period of one year from date of shipment. Any product found to be defective within this time period may be returned to Newline, freight prepaid, with prior return authorization for repair or replacement at no charge. Any damage on the products which resulted from mishandling, physical abuse, accident, unauthorized service or product abuse will have the warranty voided immediately.

Newline's liability under this warranty is limited to the repair or replacement of the defective product and in no event shall Newline be liable for consequential or indirect damages to equipment or personnel. Nor shall Newline be liable for damages to equipment or personal injury caused by misuse, overload, accidental damage, alteration, improper installation or unauthorized opening of the equipment. Under no circumstances will Newline be responsible for any indirect or consequential damages due to errors in weighing or failure of a Newline product to perform properly.

To request warranty service, please email your claim with invoice # to our Service Department, service@newlinescale.com, to request a RMA #. You can also fill out the RMA form from our web site www.newlinescale.com

NEWLINE®

STEP-ON DIGITAL BATHROOM SCALE

INSTRUCTION

For the purpose of proper using & maintaining the scale, please read this instruction completely before operating.

Electronic Bathroom Scale

Your new electronic personal scale has been designed to accurately indicate your weight gain or loss over a period of time and should give many years of service under normal use .

SPECIFICATIONS

- Equipped with a high precision strain gauge sensor system
- Capacity: 180 kgs/400lb
- Division: 0.1kg/0.2lb
- Automatic zero resetting / switch off
- Unit switch: kg / lb / st
- Low battery / over-load indicator
- Newly improved Auto Step-On Technology (no need to foot-tap activation before stepping -on)

POWER SUPPLY

- Battery: 1xCR2032 2xCR2032
- For lithium battery powered scale, please pull the insulation tape out before first using.
- When the LCD indicate "Lo", open the battery door and replace the battery with a new one.



OPERATION

STEP1: This scale must be operated on flat & solid floor for accurate results. Do not use it on carpet or rugs.

STEP2: Step on the scale evenly without moving, the scale will automatically display accurate weight in KG, LB or ST instantly. (No need to foot-tap to turn on the scale).



AUTOMATIC SWITCH OFF

The scale will be switched off automatically after 6 seconds of idle time.

OVER-LOAD INDICATOR

When the scale is over 1kg (over loaded) "Err" will appear on the screen



ADVICE FOR USE AND CARE

- Place your scale on a solid & flat surface will ensure accuracy of your scale.
- Always weigh & place your scale on a same spot
- Do not let water get into the scale, as it will damage the electronics
- Do not use this scale for legal trade
- Treat the scale with care, as it is a precision instrument. Do not drop or jump on the scale to damage the sensor